


#1 - Reading images and videos

We can import opencv module : `import cv2`

Step 1: After importing the module, we have to read the image we want to display :

```
img = cv2.imread('pic.jpg')
```

The matrix of pixels is stored in the variable



Step 2: After storing the matrix, we have to display it

```
cv2.imshow('window name', img)
```

→ (matrix of pixels)

Step 3: `cv2.waitKey(0)`

This is just a keyboard function. This waits for a specific time and waits for a key to get pressed.

0 → infinite time delay

Note :- If the dimensions of an image > computer's display resolution, the image is not completely displayed.

* We should resize the image.

Reading videos in opencv

```
video = cv2.VideoCapture('video.mp4')
```

↳ method to read video

Here, we need to continuously read a video frame by frame

```
while True:
```

```
    done, frame = video.read()
```

↳ method to read video frame by frame. Returns — (bool, frame)

```
    cv2.imshow('Video', frame) # Displaying the frames
```

```
    if cv2.waitKey(20) & 0xFF == ('k'):
```

break

- When 'k' will be pressed, loop will break

- `cv2.waitKey(20)` ← allows you to wait for specific time in milliseconds until you press any key on the keyboard.

- Higher the value in waitkey function, lesser the video speed.

```
video.release() → release the video pointer
```

For webcam capture:

```
video = cv2.VideoCapture(0) → First camera
```